

NOTES BY SYMBOL - SHEET M200

NUMBER	DESCRIPTION
1	HOLD DUCT HIGH AS POSSIBLE. COORDINATE ROUTING WITH OTHER SERVICES. EQUIPMENT AND STRUCTURE PRIOR PERFORMING WORK.
2	PROVIDE NEW "SD" SMOKE DETECTOR IN RETURN AIR DUCT PER CODE. TYPICAL.
3	NEW TEMPERATURE SENSOR IN APPROXIMATE LOCATION. MOUNT AT 48" A.F.F.
4	FULL-SIZE SUPPLY AND RETURN AIR DUCTWORK FROM RTU. TRANSITION AND OFFSET AS NECESSARY TO TERMINATE WITH CONCENTRIC DIFFUSER SIMILAR TO RUSKIN CDS. MOUNT BOTTOM OF CONCENTRIC DIFFUSER AT 22" A.F.F. COORDINATE IN FIELD WITH ARCHITECTURAL AND EQUIPMENT DRAWINGS PRIOR TO BID.
5	EXHAUST FANS TIME CLOCKS. THESE FANS TO OPERATE DURING BUILDING HOURS.
6	PROVIDE THERMOSTAT FOR UNITS WITHIN ZONER SERVED. VERIFY EXACT LOCATION, MODEL, AND TYPE WITH G.C. & OWNER.
7	DASHED LINES REPRESENT THE THROW OF THE CONCENTRIC DIFFUSER. TYPICAL.

