




KS
drawn by
KP
checked by
JULY 2024
date

revisions
1 9/13/24 ADD 01



EARLYWINE
ELEMENTARY SCHOOL
MEDIA CENTER

sheet no:

P101

OWNERSHIP USE OF DOCUMENTS:
AGP EXPRESSLY RESERVES ITS
COPYRIGHT AND OTHER PROPERTY
RIGHTS OF ALL PLANS AND DRAWINGS
DESIGNED AND/OR PRODUCED. PLANS
AND DRAWINGS ARE NOT TO BE
REPRODUCED IN ANY FORM OR MANNER
WITHOUT THE EXPRESSED WRITTEN
CONSENT OF AGP.

KEYED NOTES		GENERAL NOTES	
1	COORDINATE WALL OR CMU SIZE WITH GC FOR INSULATED 6" STORM PIPE. INSTALL PIPE FLOOR SUPPORT AT BOTTOM ELBOW. INSULATE PIPE FROM ROOF DRAIN TO WALL PENETRATION. 1" THICK INSULATION.	1.	COORDINATE WORK WITH ALL OTHER TRADES ON SITE.
2	REMOVE WATER WALL HYDRANT. CONNECT NEW INSULATED 3/4" CW TO EXISTING CW PIPE SERVING HYDRANT. EXTEND INSULATED 3/4" CW UP IN NEW CMU WALL TO ABOVE CEILING OF NEW ADDITION AND ROUTE TO NEW WALL HYDRANT.	2.	FIELD VERIFY EXISTING CONDITIONS PRIOR TO COMMENCING WORK.
4	COORDINATE WITH GC FOR ROUTING NEW 3/4" CW DOWN IN NEW CMU WALL TO NEW WALL HYDRANT.		

